# STEP-DOWN & STEP-UP TRANSFORMERS IN PROTEUS IDE

230 Volts to 12 Volts Step-down Transformer

230 Volts to 15 Volts Step-down Transformer

12 Volts to 230 Volts Step-Up Transformer

15 Volts to 230 Volts Step-Up Transformer

230 Volts to 12 Volts Step-down Center-Tapped Transformer

230 Volts to 15 Volts Step-down Center-Tapped Transformer



Embedded-DIY-Labs

LIKE, SHARE & SUBSCRIBE



#### **Turns Ratio:**

Turns Ration (n) is the ratio of the number of turns on the secondary coil  $(N_{sec})$  of an electrical transformer to the number of turns on the primary coil  $(N_{pri})$ , or vice versa.

Turns Ratio 
$$(n) = \frac{V_{sec}}{V_{pri}} = \frac{N_{sec}}{N_{pri}} = \frac{I_{pri}}{I_{sec}} = \sqrt{\frac{L_{sec}}{L_{pri}}}$$

- 1. The voltage ratio of an ideal transformer is directly related to the turn's ratio.
- 2. The current ratio of an ideal transformer is inversely related to the turn's ratio. Embedded-DIY-Labs
- 3. The turn's ratio of an ideal transformer by inductance is the square root of the inductance ratio values

#### Open-Circuit Voltage Ratio by Inductance:

$$\frac{V_{sec}}{V_{pri}}$$
 (open circuit)  $=\frac{M}{L_{pri}}$ 

MUTUAL INDUCTANCE ( 
$$M$$
 )  $= K \sqrt{L_{pri} \; L_{sec}}$ 



Then,

$$\frac{V_{sec}}{V_{pri}} (open circuit) = \frac{K \sqrt{L_{pri} L_{sec}}}{L_{pri}}$$

### Max-Coupled Voltage Ratio by Inductance:

If the ratio of all the flux is coupled to the ratio of the turns, then

$$\frac{V_{sec}}{V_{pri}}(max-coupled) = \frac{K\sqrt{L_{sec}}}{\sqrt{L_{pri}}}$$

# K - Coupling Coefficient ded-DIY-Labs

Ideal transformer has a coupling coefficient equal to 1 (unity).

$$\frac{V_{sec}}{V_{pri}} = \sqrt{\frac{L_{sec}}{L_{pri}}}$$

Then,

$$\frac{L_{sec}}{L_{pri}} = \left(\frac{V_{sec}}{V_{pri}}\right)^2$$

## Proteus: Step-down Transformer Design

#### 230 Volts to 12 Volts Step-down Transformer

$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

Let's assume,

 $L_{pri} = 1 Henry,$ 

 $V_{pri} = 230 \, Volts$  (Applied Input RMS Voltage - It depends on available Source Voltage)

 $V_{sec} = 12 Volts$  (Required step-down Voltage)



$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

$$L_{sec} = (\frac{V_{sec}}{V_{pri}})^2 x L_{pri}$$


$$L_{sec} = (\frac{12}{230})^2 x 1$$

 $L_{sec} = 0.002722 Henry$ 

# <u>Proteus Transformer Design</u> INPUT

#### Step-1:

In AC Source, enter Peak Voltage.



So, Peak Voltage of RMS Input Voltage = 230 V is,


$$PEAK.V_{pri} = 1.414 \times 230 V$$

$$PEAK.V_{pri} = 325 V$$

$$FREQUENCY = 50 HZ$$




#### In Transformer,



$$L_{pri}=1\ Henry$$
  $L_{sec}=0.002722\ Henry$  Coupling Factor (K) = 1







### 230 Volts to 15 Volts Step-down Transformer


$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

Let's assume,

 $L_{pri} = 1 Henry,$ 

 $V_{pri} = 230 \, Volts$  (Applied Input RMS Voltage - It depends on available Source Voltage)

 $V_{sec} = 15 Volts$  (Required step-down Voltage)



$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

$$L_{sec} = (\frac{V_{sec}}{V_{pri}})^2 x L_{pri}$$

$$L_{sec} = (\frac{15}{230})^2 x 1$$


 $L_{sec} = 0.004253 Henry$ 

### **Proteus Transformer Design**

#### INPUT

#### Step-1:

In AC Source, enter Peak Voltage.



So, Peak Voltage of RMS Input Voltage = 230 V is,


$$PEAK.V_{pri} = 1.414 \times 230 V$$

$$PEAK.V_{pri} = 325 V$$

$$FREQUENCY = 50 HZ$$




#### In Transformer,



$$L_{pri}=1\ Henry$$
  $L_{sec}=0.004253\ Henry$  Coupling Factor (K) = 1







## Proteus: Step-Up Transformer Design

#### 12 Volts to 230 Volts Step-Up Transformer

$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

Let's assume,

 $L_{pri} = 1 Henry,$ 

 $V_{pri} =$  12 Volts (Applied Input RMS Voltage - It depends on available Source Voltage)

 $V_{sec} = 230 \, Volts$  (Required step-Up Voltage)

$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

$$L_{sec} = (\frac{V_{sec}}{V_{pri}})^2 x L_{pri}$$

$$L_{sec} = (\frac{230}{12})^2 x 1$$


$$L_{sec} = 367.36 \, Henry$$

## **Proteus Transformer Design**

#### INPUT

#### Step-1:

In AC Source, enter Peak Voltage.



So, Peak Voltage of RMS Input Voltage = 12 V is,


$$PEAK.V_{pri} = 1.414 x 12 V$$

$$PEAK.V_{pri} = 16.97 V$$

$$FREQUENCY = 50 HZ$$




#### In Transformer,



$$L_{pri}=1\ Henry$$
  $L_{sec}=367.36\ Henry$  Coupling Factor (K) = 1







#### 15 Volts to 230 Volts Step-Up Design

$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

Let's assume,

 $L_{pri} = 1 Henry,$ 

 $V_{pri} = 15 \, Volts$  (Applied Input RMS Voltage - It depends on available Source Voltage)

 $V_{sec} = 230 \, Volts$  (Required step-Up Voltage)



$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

$$L_{sec} = (\frac{V_{sec}}{V_{pri}})^2 x L_{pri}$$

$$L_{sec} = (\frac{230}{15})^2 x 1$$


$$L_{sec} = 235.11 Henry$$

### **Proteus Transformer Design**

#### INPUT

#### Step-1:

In AC Source, enter Peak Voltage.




So, Peak Voltage of RMS Input Voltage = 15 V is,

$$PEAK.V_{pri} = 1.414 x 15 V$$
 $PEAK.V_{pri} = 21.21 V$ 
 $FREQUENCY = 50 HZ$ 




#### In Transformer,



$$L_{pri}=1\ Henry$$
  $L_{sec}=235.11\ Henry$  Coupling Factor (K) = 1







# Proteus: Step-down Center - Tapped Transformer Design

# 230 Volts to 12 Volts Step-down Center - Tapped <u>Transformer</u>

$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

Let's assume,

 $L_{pri} = 1 Henry,$ 

 $V_{pri}$  = 230 Volts (Applied Input RMS Voltage - It depends on available Source Voltage)

 $V_{sec} = 12 Volts$  (Required step-down Voltage) IY-Labs

$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

$$L_{sec} = (\frac{V_{sec}}{V_{pri}})^2 x L_{pri}$$


$$L_{sec} = (\frac{12}{230})^2 x 1$$

 $L_{sec} = 0.002722 Henry$ 

# <u>Proteus Transformer Design</u> INPUT

#### Step-1:

In AC Source, enter Peak Voltage.



So, Peak Voltage of RMS Input Voltage = 230 V is,


$$PEAK.V_{pri} = 1.414 \times 230 V$$

$$PEAK.V_{pri} = 325 V$$

$$FREQUENCY = 50 HZ$$



#### In Transformer,



$$L_{pri} = 1 Henry$$


Since it's a center - tapped we have to apply

$$L_{sec} = 2 x 0.002722 Henry$$

$$L_{sec} = 0.005444 Henry$$

# Coupling Factor (K) = 1







# 230 Volts to 15 Volts Step-down Center - Tapped <u>Transformer</u>

$$\frac{L_{sec}}{L_{pri}} = (\frac{V_{sec}}{V_{pri}})^2$$

Let's assume,

 $L_{pri} = 1 Henry,$ 

 $V_{pri} = 230 \, Volts$  (Applied Input RMS Voltage - It depends on available Source Voltage)

 $V_{sec} = 15 Volts$  (Required step-down Voltage)

$$\underbrace{\frac{L_{sec}}{L_{pri}}} \underbrace{\frac{V_{sec}}{V_{pri}}}^{2-Labs}$$

$$L_{sec} = (\frac{V_{sec}}{V_{pri}})^2 x L_{pri}$$


$$L_{sec} = (\frac{15}{230})^2 x 1$$

 $L_{sec} = 0.004253 Henry$ 

# <u>Proteus Transformer Design</u> INPUT

#### Step-1:

In AC Source, enter Peak Voltage.



So, Peak Voltage of RMS Input Voltage = 230 V is,


$$PEAK.V_{pri} = 1.414 \times 230 V$$

$$PEAK.V_{pri} = 325 V$$

$$FREQUENCY = 50 HZ$$



#### In Transformer,



$$L_{pri} = 1 Henry$$


Since it's a center - tapped we have to apply

$$L_{sec} = 2 \times 0.004253 Henry$$

$$L_{sec} = 0.008506 Henry$$

## Coupling Factor (K) = 1







#### Important-Note:

In Step-Up Transformer Design, We Can also apply the Respective Step-down Inductor Values Vice-Versa.

i.e.,

Step-1: Step-down  $L_{pri}$  Value to  $L_{sec}$  Value of step-up

Step-2: Step-down  $L_{sec}$  Value to  $L_{pri}$  Value of step-up

This can be achieved by finding the  $L_{pri}$  Value instead of  $L_{sec}$  by keeping  $L_{sec}$  Value as 1 Henry instead of  $L_{pri}$  Value as 1 Henry by default.

$$L_{pri} = \left(\frac{V_{pri}}{V_{sec}}\right)^2 x L_{sec}$$

#### THANK-YOU!



Note: Incase of any queries, Comment Us!

